

響のホール調光回路表

負荷名称	UH-1	UH-2	UH-3	UH-4	LH上下-1	LH上下-2	LH上下-3	LH上下-4	1Br-1	1Br-2	1Br-3	1Br-4
DMX	1	2	3	4	5	6	7	8	9	10	11	12
相	R	S	T	R	S	T	R	S	T	R	S	T
備考	#71	#72	#63	#22	#72	#59	#22	#40				
負荷名称	1Br-5	1Br-6	1Br-7	1Br-8	2Br-1	2Br-2	2Br-3	2Br-4	2Br-5	2Br-6	2Br-7	2Br-8
DMX	13	14	15	16	17	18	19	20	21	22	23	24
相	R	S	T	R	S	T	R	S	S	T	R	S
備考												
負荷名称	3Br-1	3Br-2	3Br-3	3Br-4	3Br-5	3Br-6	3Br-7	3Br-8	1LB-1	1LB-2	1LB-3	1LB-4
DMX	25	26	27	28	29	30	31	32	33	34	35	36
相	T	R	S	T	R	S	T	R	R	S	T	R
備考												
負荷名称	1LB-5	1LB-6	1LB-7	1LB-8	2LB-1	2LB-2	2LB-3	2LB-4	2LB-5	2LB-6	2LB-7	2LB-8
DMX	37	38	39	40	41	42	43	44	45	46	47	48
相	S	T	R	S	T	R	S	T	T	R	S	T
備考												
負荷名称	3LB-1	3LB-2	3LB-3	3LB-4	3LB-5	3LB-6	3LB-7	3LB-8	UHC-1	UHC-2	UHC-3	UHC-4
DMX	49	50	51	52	53	54	55	56	57	58	59	60
相	R	S	T	R	S	T	R	S	S	T	R	S
備考												
負荷名称	FS上-1	FS上-2	FS上-3	FS上-4	FST下-1	FST下-2	FST下-3	FST下-4	FC上-1	FC上-2	FC上-3	FC上-4
DMX	61	62	63	64	65	66	67	68	69	70	71	72
相	T	R	S	T	R	S	T	R	R	S	T	R
備考	下段より			▶	下段より			▶				
負荷名称	FC下-1	FC下-2	FC下-3	FC下-4	FC奥-1	FC奥-2	FC奥-3	FC奥-4	FC客上-1	FC客上-2	FC客下-1	FC客下-2
DMX	73	74	75	76	77	78	79	80	81	82	83	84
相	S	T	R	S	T	R	S	T	T	R	S	T
備考												
負荷名称	客席-1	客席-2	客席-3	舞台-1	舞台-2	客席-4	客席-5	客席-6	客席-7	客席-8	客席-9	客席-10
DMX	85	86	87	88	89	90	91	92	93	94	95	96
相	R	S	T	R	S	T	R	S	S	T	R	S
備考	PA席	PA席周り	2F席	作業灯	作業灯	客席前	客席前	客席後	客席後	空き回路	上壁面1	上壁面2
負荷名称	客席-11	客席-12	客席-13	客席-14	2LB Unit-1	2LB Unit-2	2LB Unit-3	3LB Unit-1	3LB Unit-2	3LB Unit-3	UH Unit-1	UH Unit-2
DMX	97	98	99	100	101	102	103	104	105	106	107	108
相	T	R	S	T								
備考	上壁面3	下壁面1	下壁面2	下壁面3	Unit no.1	Unit no.1	Unit no.1	Unit no.2	Unit no.2	Unit no.2	Unit no.3	Unit no.3

